
EASY-FIT SHED SUPPORT FRAME (FLEXISTORE 1533)


COMPATIBILITY
This support frame is compatible with Asgard Flexistore 1533 sheds. The frame dimensions and components will vary depending on the specific shed model.


TOOLS REQUIRED
Screwdriver, Posi-Driv Screwdriver, 10mm Spanner, 14mm Spanner, 4mm Allen Key, Spirit Level



ASGFRAEXTBRKT **065948** x2


FOOT CHANNEL
ASGFRABAG x2
(x4 FEET EACH)






For maintenance instructions of this product visit www.asgardsss.co.uk

1! PLACE THE FOOT CHANNEL IN THE SUPPORT FRAME AND ATTACH USING 2 ZSCREW254.




x2

2! ATTACH THE REMAINING 3 FOOT CHANNELS TO THE SUPPORT FRAME (065949). REPEAT FOR SECOND FRAME (065949).




x6

3! SECURE CONNECTOR BRACKETS IN PLACE USING 4 ZSCREW254 (2 PER BRACKET).




x4

4! POSITION THE EXTENSION FRAME (065950) AND FIX IN PLACE USING 4 ZSCREW254 (2 PER BRACKET). REPEAT FOR THIRD FRAME (065949).




x4

5! SECURE THE SHED BASE TO THE SUPPORT FRAMES USING 12 ZSCREW403 AND A 10MM SPANNER.



x12

6! WE ADVISE SECURING THE SUPPORT FRAME TO THE FLOOR BY USING 8 ZSCREW32 WITH A 10MM SPANNER. (THE 8 ZSCREW32 COME WITH YOUR SHED).



x8